


PHUNZONE

CURVED SLIDE ASSEMBLY Three Options


1. No Frame



2. Tube Frame



3. Raised Frame
for Ballpits/Pools






These “generic “ instructions are for a “tube frame” set-up. Adapt as necessary



STEP 1

- assemble base frame
- turn run-out upside-down
- attach frame to yellow run-out
- use 2 black panel screws
- 1/4 turn to lock in



STEP 2


- place slide next to the run-out and frame
- the slide must “overlap” the yellow-run-out


Recommend that you use a large steel screwdriver

STEP 3

- yellow **nut** fits inside round hole of the run-out (facing outward)
- small “**stud**” on **nut** needs to face “**outward**”
- stud fits into “**slot**” in the hole
- blue screw fits from outside into the “**nut**”
- 1/4 turn to lock in


Yellow Nut +
Blue Screw





STEP 5


- finish construction of main structure
- ensure you have the connectors properly placed to accept slide frame tubes
- attach slide to main structure



- with 3 holes
- set off angle @ 45 degrees

STEP 6


- attach top curved lip of slide with "Black" screws
- attach side handles of slide with "Blue" screws




"Waterslide"

Attach a water hose to the small nipple on the back of the slide or attach to top of the slide

Platform and wall instructions for larger commercial-type designs



Plexi for green slide
Special notch cut-out is
only where the slide
mounting handle is
"perpendicular" to the
plexi panel



Green Curved Slide

- Ensure platform panels are oriented as per the diagram (different for red/green slide)
- NO NOT LOCK IN ANY TUBES or PANELS IN THE AREA OF THE PLEXI
- Insert special "U" - shaped plexi clips into side "Vertical" tubes
- Insert the Plexi panel onto the bottom clips first - then rotate up to the top clips
- Push vertical tubes together so plexi is well seated in the clips
- Close and lock in all the tubes

PLATFORM PANEL SCREW SEQUENCING

Green Slide

- fasten GREEN **slide** to the platform's horizontal **tube** with the "**black**" panel screws;
- continue to "alternate" the direction of the panels as per the diagram

